

## T5581\_PPS note

Some testers with 0.8A PPS are also available.

TEST HEAD 1	DC CONFIGURATION [1-32] .....	>	1-32
	10V PPS SPEC [1,2] (1:0.4A 2:0.8A) .....	>	2
	10V PPS CONFIGURATION [1-64] .....	>	1-64
	16V PPS CONFIGURATION [33-64] .....	>	
	HV PPS CONFIGURATION [1-4] .....	>	
TEST HEAD 2	DC CONFIGURATION [1-32] .....	>	1-32
	10V PPS SPEC [1,2] (1:0.4A 2:0.8A) .....	>	2
	10V PPS CONFIGURATION [1-64] .....	>	1-64
	16V PPS CONFIGURATION [33-64] .....	>	
	HV PPS CONFIGURATION [1-4] .....	>	